

XP-3179-S v. 2.1b

Installation

XP-DE5047

- Installation Time: About 20 minutes
- Tools Required: 1/4" Nut-driver, Phillips screwdriver
 - 1. Unplug the AC power from your pinball machine. Remove game backglass. Open back box.
 - 2. Remove existing power supply.
 - 3. Install fuses provided per silk screen.
 - 4. Install the XP-DE5047 into the back box.
 - 5. Connect all connectors as indicated.
 - 6. Double-check all connections, plug in the machine, and turn the game on.
 - 7. All systems should be operational! Play on!

