

XP-3179-S v. 2.1b

Installation

XP-BLY2518-58 (7 Digit Display)

- Installation Time: About 7 minutes
- Tools Required: None
- 1. Unplug the AC power from your pinball machine. Remove game Backglass.
 Unplug all display board connecting cables and remove the original glass display circuit boards.
- 2. JP1: If a comma is desired in your score leave the jumper on JP1, remove if no comma is wanted.
- 3. JP2: Used for an upcoming feature. Remove and place on a single pin.
- 4. Assemble the Driver Board and Display Board as shown in the illustration below.
- 5. Slide the assembly into the tray in the Backboard and plug existing cable assembly into the board.
- 6. Install Foam Light Blocks around the displays and attach vinyl film if desired.
- 7. Close it up and install the Backglass. You are now ready to play!



