

Installation

XP-GTLB6

■ Installation Time: About 5 minutes

■ Tools Required: None

- 1. Unplug the AC power from your pinball machine. Remove game back glass. Open back box.
- 2. Remove OEM Display from game.
- 3. Prior to installing the display, verify fit of the light gasket and apply the appropriate colored vinyl film to the display.
- 4. Install XP-GTLB6 display.
- 5. Plug AC Power and turn game on.
- 6. Adjust display to the desired brightness
- 7. Re-Install back glass and close the back box.
- 8. All systems should be operational! Play on!

